




Panel Autoland Warnings Airbus A320
A320 Autoland Warnings panel



Datos técnicos:
Technical data:

Las medidas del producto (ancho x alto x profundidad) son: 330 x 81,5 x 6 mm.
The measurements of the product (width x height x depth) are: 330 x 81,5 x 6 mm.




Datos de Montaje:
Assembly data:



* Cableado de los interruptores tipo Korry.
Korry switch type wiring detail.



Esquema de montaje:
Assembly scheme:



* Ejemplo de cableado del panel.
Panel wiring example.



* Atornillar los tornillos del panel en la estructura MIP.

Fix the panel screws into the MIP structure.

* Cablear el panel a las tarjetas de entrada y salida.

Wiring the panel to the input and output cards.

Precaución:

Caution:

* Montar y fijar adecuadamente el panel.

Mount and fix the panel properly.

* Panel comprobado para funcionar a la tensión de salida que proporciona la tarjeta master.

Panel checked to operate at the output voltage provided by the Opencockpits Master Card.

Declaración de entradas y salidas:

I/O declaration:

//Salidas - Outputs

```
VAR XXX, NAME AUTO, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME LAND, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME MASTER, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME CAUT, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME MASTER2, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME WARN, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME ARROW, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
VAR XXX, NAME CAPT_FO, LINK IOCARD_OUT, DEVICE X, OUTPUT XX
```

//Entradas - Inputs

```
Var XXX, NAME AUTOLAND, Link IOCARD_SW, DEVICE X, Input XX
Var XXX, NAME MASTERCAUT, Link IOCARD_SW, DEVICE X, Input XX
Var XXX, NAME MASTERWARN, Link IOCARD_SW, DEVICE X, Input XX
Var XXX, NAME PRIORITY, Link IOCARD_SW, DEVICE X, Input XX
Var XXX, NAME CHRONO, Link IOCARD_SW, DEVICE XX, Input XX
```